



User Manual

TORT-1550 Optical Rack Transmitter - 1550nm

| Article | | Article no. |
|-----------|-----------------------------------|-----------------|
| TORT-1550 | Optical Rack Transmitter - 1550nm | 307916 |
| Version | V2.0 | Date 2025/06 EN |

Table of content

| | | |
|----------|---|-----------|
| 1 | Safety Instructions | 3 |
| 2 | Introduction..... | 5 |
| 2.1 | Product description..... | 5 |
| 2.2 | Detailed features..... | 5 |
| 2.3 | Installation | 5 |
| 2.4 | Installation schematic example..... | 6 |
| 2.5 | Front panel..... | 7 |
| 2.6 | Rear panel | 8 |
| 2.7 | Navigating through the menu | 9 |
| 3 | Block diagram | 12 |
| 4 | Technical Specifications | 13 |
| 5 | Web server | 14 |
| 6 | Resolution of common issues | 22 |
| 7 | EU Declaration of Conformity | 22 |
| 8 | Conditions of warranty..... | 23 |

1 Safety Instructions



Read these instructions carefully before connecting the unit

ATTENTION

- Failure to comply with the specified precautionary measures may cause serious injury to persons or damage to property.
- The assembly, installation, additional electrical wiring, servicing and commissioning may only be performed by suitably qualified persons, technicians or installers in compliance with safety regulations.
- Damage due to improper installation and commissioning, defective connectors on cables or any other incorrect handling will void the warranty.

CAUTION

- The safety requirements are according to the standards EN 62368-1 resp. EN 60728-11 and must be observed, especially concerning equipotential bonding and earthing.
- Observe the relevant country-specific standards, regulations and guidelines on the installation and operation of antenna systems.
- Before starting installation or service work disconnect the receiving system from mains.
- Installation or service work should NEVER be undertaken during electrical / thunderstorms.
- Avoid short circuits!
- To ensure electromagnetic compatibility, make sure all connections are tight and that the covers are screwed on securely.
- Take action to prevent static discharge when working on the device!
- Due to the risk of fires caused by lightning strikes, we recommend that all mechanical parts (e.g. distributor, equipotential bonding rail, etc.) be mounted on a non-combustible base. Wood panelling, wooden beams, plastic covered panels and plastic panels are all examples of combustible bases.



To prevent fire, short circuit or shock hazard:

- Do not expose the unit to rain or moisture.
- Install the unit in a dry location without infiltration or condensation of water.
- Do not expose it to dripping or splashing.
- Do not place objects filled with liquids, such as vases, on the apparatus.
- If any liquid should accidentally fall into the cabinet, disconnect the power plug.



To avoid any risk of overheating:

- Install the unit in a well aired location and keep a minimum distance of 5 cm around the apparatus for sufficient ventilation.
- Do not place any items such as newspapers, tablecloths, curtains, on the unit that might cover the ventilation holes.
- Do not place any naked flame sources, such as lit candles, on the apparatus.
- Do not install the product in a dusty place.
- Use the apparatus only in moderate climates (not in tropical climates).
- Respect the minimum and maximum temperature specifications.



To avoid any risk of electrical shocks:

- Connect apparatus only to a power socket with a protective earth connection.
- The mains plug shall remain readily operable.
- Pull out power plug to make the different connections of cables.
- To avoid electrical shock, do not open the housing of the product.



Warning

LASER RADIATION
DO NOT VIEW DIRECTLY WITH OPTICAL INSTRUMENTS
CLASS 1M LASER PRODUCT

To avoid exposure to laser radiation from optical fibre or active optical devices like transmitters or receivers which pose a hazard to your health, you should:

- Never look into an exposed end of an optical fibre or mirror surfaces that could reflect light from an open optical fibre.
- Never look into an optical fibre connected with the radiation source with optical instruments (magnifying glass, microscope, etc...).
- Use an approved fibre optic cable to maintain conformity with applicable laser safety requirements.

Concerning fibre optic cables:

- Wearing protective goggles is recommended.
- You should handle fibre optic cables with extreme caution, particularly when unbundling or terminating a cable. The internal glass core of a fibre optic cable is brittle when the shielding and buffer material is removed. It will easily disintegrate into small pieces which may cause injury to the human body.
- Remove all filings immediately using tweezers, place them in a tightly sealed dustbin and dispose in accordance with local regulations.



Maintenance



Only use a dry soft cloth to clean the cabinet.



Do not use solvent.



For repairing and servicing, refer to qualified personnel.



Dispose according your local authority's recycling processes

Electronic devices should never be disposed of in the household rubbish. In accordance with directive 2002/96/EC of the European Parliament and the European Council from January 27, 2003 which addresses old electronic and electrical devices, such devices must be disposed of at a designated collection facility. At the end of its service life, please take your device to one of these public collection facilities for proper disposal.

2 Introduction

2.1 Product description

The TRIAX TORT-1550 is a Rack mount 1550nm Optical Transmitter to carry CATV &/or one band of IF satellite to your EDFA/EYDFA for larger optical networks. Use with TRIAX TOFA range of EYDFA and TOMR-CATV optical CATV/IF receiver. Supports TRIAX TDMH & TDcH headend fibre distribution.

- 47-2400MHz (RF + Sat) 1550nm Optical 1U rack Transmitter 5dBm
- 1550nm EDFA/ EYDFA compatible
- LCD Front Panel display for easy status monitoring
- Front Panel operation of basic functions with key lock
- RF Test Port on front panel
- Remote SNMP & Web Supported
- Dual hot plug power supply
- Intuitive GUI Management

2.2 Detailed features

TORT-1550 is compatible with any FTTx PON technology to realize multi networks integration of CATV (Analog & Digital), satellite TV (DVB-S/S2) and terrestrial TV.

- Single input, frequency 47~862MHz & 950~2400MHz
- Predistortion circuit ensuring CTB and CSO performances in high standard CNR value
- Built-in APC and ATC control circuits ensure the long life and reliability of the laser
- High linear RF/IF driving amplifying circuit with AGC function to ensure high-quality transmission of analogue TV and digital TV (DVB-S/S2, DVB-C, DVB-T)
- All signals in a single fibre
- OMI can be adjusted and optimized to support different networks
- Automatic temperature control, fans starting to work when rack temperature reaches 30°C
- Built-in dual backup power supply, hot plug and automatic switch supported
- Working parameters of the transmitter are controlled by microprocessor
- LCD status display on the front panel has many functions such as laser status monitoring, parameter display, fault alarm, network management, etc...
- If the working parameters of the laser deviate from the allowed range set by the software, the system will alarm promptly
- Standard RJ45 interface supporting SNMP and WEB remote network management and remote adjustment of AGC, OMI and other functions


2.3 Installation

Preparation before installation:

- **Observe instructions given at chapter 1**
- Install the unit in a well aired location and keep a minimum distance of 5 cm around the transmitter for sufficient ventilation. Please don't block the cooling holes of the device
- Connect the transmitter only to a power socket with protective earth connection
- Please make sure the key is turned to OFF before connecting the power supply
- Please ensure the interface of the fibre is clean before connecting the fibre
- Fibre connector should be SC/APC (green), if needed clean the connector with the right tool
- Only connect RF input after approximately two minutes when the device is in a stable status

- **RF input level should not be too high, otherwise the laser will be overloaded and damaged**
- Inside the transmitter there is a static-sensitive laser, please note that electrostatic protection should be applied in the storage of the transmitter and it should not be stored with corrosive material. The storage temperature should be between -40°C and +85°C.

2.4 Installation schematic example





2.5 Front panel



| Identification | Item | Remark |
|----------------|----------------------------|--|
| LCD | LCD display | To display the transmitter's parameters |
| STATUS | Transmitter working status | Green: transmitter is operating Red: transmitter faulty or alarm |
| LASER | Laser output | Green: Output within normal range Red: Output out of normal range |
| RF | RF input | Green: input within nominal range Yellow: no signal or input out of nominal range |
| POWER | Power supply | Green: dual power supply working Yellow: single power supply working |
| ▲▼ | Buttons (arrows) | Start menu page turning and set the transmitter |
| ENT | Enter | Confirmation after menu page turning and device setting |
| OFF/ON | Key | ON: Laser ON OFF: Laser OFF |
| RF TEST | RF test point | RF input level -20dB |


2.6 Rear panel





| Identification | Item | Remark |
|---|--------------------|--|
| Fan | Fan | Starts working when rack temperature reaches 30°C |
| RF INPUT | RF INPUT | Input for CATV &/or single band SAT-IF |
|  | LNB voltage switch | +12V: to receive vertical polarization IF signal O: LNB Voltage OFF +18V: to receive Horizontal polarization IF signal |
|  | Grounding Port | For Grounding |
| OPT OUT | Fibre output | |
| RS232 | RS232 Port | Local programming |
| RJ45 | RJ45 Port | Remote SNMP and WEB support |
| Power1 | Power Socket1 | Hotplug supported |
| Power2 | Power Socket 2 | Hotplug supported |

2.7 Navigating through the menu


Press the ▼ to display the following menu and press the ▲ to display the previous menu







3 Block diagram




4 Technical Specifications

| Category | Items | Unit | Min. | Value Typ. | Max. | Remarks |
|----------|------------------------------|--------------------|----------------------------------|---------------|------|---------------------------------------|
| Optical | Laser wavelength | nm | 1540 | 1550 | 1550 | 1550nm compatible with ITU wavelength |
| | No. of output ports | - | - | 1 | - | - |
| | Output power per port | dBm | - | 5 | - | 1550nm |
| | Laser linewidth | MHz | - | 0.65 | 1.0 | - |
| | SMSR | dB/Hz | 45 | 50 | - | - |
| | RIN | dB | - | - | -160 | RIN (20-2600MHz) |
| | Optical return loss | dB | 50 | - | - | - |
| | Fibre connector | - | SC/APC | | | - |
| IF | Operating bandwidth | MHz | 47 | - | 2400 | - |
| | Input level | dBm | -40 | - | -25 | - |
| | Flatness | dB | -2.0 | - | +2.0 | @ 950 - 2400MHz |
| | Return loss | dB | 10 | - | - | - |
| | Input impedance | Ω | - | 75 | - | - |
| | RF connector | - | F type | | | - |
| | Number of test channels | - | - | 36 | - | - |
| | CNR | dB | 28 | - | - | - |
| | CTB | dB | 36 | - | - | - |
| | CSO | dB | 36 | - | - | - |
| | LNB voltage | V | 0/13/18 | | | Switchable |
| | LNB current | mA | - | - | 300 | - |
| General | Network management interface | - | SNMP, WEB supported | | | - |
| | Power supply | V | 90 | - | 265 | AC |
| | Frequency | Hz | | 50/60 | | |
| | Power consumption | W | - | - | 30 | Dual power supply, 1+1 standby |
| | Operating temperature | $^{\circ}\text{C}$ | -5 | - | +65 | Auto case temp control |
| | Storage temperature | $^{\circ}\text{C}$ | -40 | - | +85 | - |
| | Operating relative humidity | % | 5 | - | 95 | - |
| | Altitude operation | m | Max. 2000 meters above sea level | | | - |
| | Dimension | mm | 370 × 483 × 44 | | | D x W x H |
| | Weight | Kg | 3.8 | | | - |


5 Web server

An SNMP Web server is built in. Users can directly view the basic operating parameters and network parameters of the transmitter through web browsers like IE Microsoft IE, Google Chrome, Mozilla Firefox, software ASA's opera, etc. The built-in SNMP web server supports these browsers. The following screenshots are illustrated by opera browser.



First, find the IP address of the transmitter in the LCD panel menu. The default IP address is 192.168.0.22. Set the IP address of the computer to the same network segment as the device, find the "network" icon on the desktop of windows system, select the icon, right-click the mouse, and select "properties" in the pop-up menu




Click "Local Area Connection" in the pop-up version




In the “Local Area Connection Status” menu, select “Properties”, and then double-click “Internet Protocol Version 4 (TCP / IPv4)”.




Set the IP address of your PC to be in the same network segment as the device, so that the computer can access the GUI.



Open the web browser and enter the IP address of the device in the address bar of the browser, such as 192.168.0.22




The browser will pop up a login box




In the pop-up login username box, enter User Name: "admin" (Note: all lowercase letters), Password: "123456", and then enter.

The browser displays the device status page by default



Real Time Device Status Page

The left side of the page is the menu navigation bar. Click to enter the corresponding menu page



Menu Navigation Bar

TRIAX

Device Status
Device Settings
Alarm Status
Alarm Properties
Network Settings
Change Password
Reset Settings
Update Firmware
Device Logs

Device Settings

Laser Status: Laser ON

Set

OMI Mode: AGC

Set

OMI Value: 0.0 dB (-3.0~3.0)

Set

MGC ATT: 15.0 dB (0~15.0)

Set

Copyright © All rights reserved.

Device Settings Page

TRIAX


Device Status
Device Settings
Alarm Status
Alarm Properties
Network Settings
Change Password
Reset Settings
Update Firmware
Device Logs

Alarm Status

| Index | Parameter Name | Alarm Status |
|-------|------------------|--------------|
| 1 | Unit Temperature | Nominal |
| 2 | Drive Level | LO |
| 3 | Laser TEMP | Nominal |
| 4 | Laser BIAS | Nominal |
| 5 | Laser Opt-output | Nominal |
| 6 | Laser TEC | Nominal |
| 7 | DC +24V | Nominal |
| 8 | DC +18V | Nominal |
| 9 | DC +12V | Nominal |
| 10 | DC +5V | Nominal |
| 11 | DC -5V | Nominal |
| 12 | DC +3.3V | Nominal |

Copyright © All rights reserved.

Alarm Status Page



Device Status

Device Settings

Alarm Status

Alarm Properties

Network Settings

Change Password

Reset Settings


Update Firmware

Device Logs

Alarm Properties

| Index | Parameter Name | HHI | HI | LO | LOLO | Deadband | Action |
|-------|-----------------------|---|---|--|--|----------|---------------------|
| 1 | Unit Temperature (°C) | <input checked="" type="checkbox"/> 85 | <input checked="" type="checkbox"/> 70 | <input checked="" type="checkbox"/> 5 | <input checked="" type="checkbox"/> 0 | 2 | Set |
| 2 | Drive Level (dBuV) | <input checked="" type="checkbox"/> 120 | <input checked="" type="checkbox"/> 110 | <input checked="" type="checkbox"/> 90 | <input checked="" type="checkbox"/> 60 | 1 | Set |
| 3 | Laser TEMP (°C) | <input checked="" type="checkbox"/> 40.0 | <input checked="" type="checkbox"/> 35.0 | <input checked="" type="checkbox"/> 15.0 | <input checked="" type="checkbox"/> 10.0 | 1.0 | Set |
| 4 | Laser BIAS (mA) | <input checked="" type="checkbox"/> 150.0 | <input checked="" type="checkbox"/> 120.0 | <input checked="" type="checkbox"/> 20.0 | <input checked="" type="checkbox"/> 10.0 | 1.0 | Set |
| 5 | Laser Opt-output (mW) | <input checked="" type="checkbox"/> 40.0 | <input checked="" type="checkbox"/> 38.0 | <input checked="" type="checkbox"/> 1.0 | <input checked="" type="checkbox"/> 0.5 | 0.1 | Set |
| 6 | Laser TEC (A) | <input type="checkbox"/> 3.00 | <input type="checkbox"/> 2.00 | <input type="checkbox"/> -2.00 | <input type="checkbox"/> -3.00 | 0.10 | Set |
| 7 | DC +24V (V) | <input checked="" type="checkbox"/> 28.0 | <input checked="" type="checkbox"/> 26.0 | <input checked="" type="checkbox"/> 22.0 | <input checked="" type="checkbox"/> 20.0 | 0.1 | Set |
| 8 | DC +18V (V) | <input checked="" type="checkbox"/> 20.0 | <input checked="" type="checkbox"/> 19.0 | <input checked="" type="checkbox"/> 17.0 | <input checked="" type="checkbox"/> 16.0 | 0.1 | Set |
| 9 | DC +12V (V) | <input checked="" type="checkbox"/> 14.0 | <input checked="" type="checkbox"/> 13.0 | <input checked="" type="checkbox"/> 11.0 | <input checked="" type="checkbox"/> 10.0 | 0.1 | Set |
| 10 | DC +5V (V) | <input checked="" type="checkbox"/> 6.5 | <input checked="" type="checkbox"/> 6.0 | <input checked="" type="checkbox"/> 4.0 | <input checked="" type="checkbox"/> 3.5 | 0.1 | Set |
| 11 | DC -5V (V) | <input checked="" type="checkbox"/> -3.5 | <input checked="" type="checkbox"/> -4.0 | <input checked="" type="checkbox"/> -6.0 | <input checked="" type="checkbox"/> -6.5 | 0.1 | Set |
| 12 | DC +3.3V (V) | <input checked="" type="checkbox"/> 4.1 | <input checked="" type="checkbox"/> 3.8 | <input checked="" type="checkbox"/> 2.8 | <input checked="" type="checkbox"/> 2.5 | 0.1 | Set |

Alarm Properties Setting Page



Device Status

Device Settings

Alarm Status

Alarm Properties

Network Settings

Change Password

Reset Settings

Update Firmware

Device Logs

Network Settings

Device MAC: 00: B9: A0: 13: 18: ED

Update Identifier: OTD138EG02

Agent Version: v1.0.1 [Refresh](#)

Static IP Address: [Set](#)

Subnet Mask: [Set](#)

Default Gateway: [Set](#)

Trap Address 1: [Set](#)

Trap Address 2: [Set](#)

Trap Address 3: [Set](#)

Trap Address 4: [Set](#)

Trap Address 5: [Set](#)

Trap Address 6: [Set](#)

Trap Address 7: [Set](#)

Trap Address 8: [Set](#)

IPv6 Global Unicast:

IPv6 Local Link: fe80::2b9:a0ff:fe13:18ed

Trap IPv6 Host1: [Set](#)

Trap IPv6 Host2: [Set](#)

Trap IPv6 Host3: [Set](#)

Trap IPv6 Host4: [Set](#)

Trap IPv6 Host5: [Set](#)


Trap IPv6 Host6: [Set](#)

Trap IPv6 Host7: [Set](#)


Trap IPv6 Host8: [Set](#)

Copyright © All rights reserved.


Network Settings Page




Page to Change Username and Password



Restore Page



Firmware update page



Device logs page

6 Resolution of common issues

| S/N | Phenomenon | Possible reason | Solution |
|-----|--|--|--------------------------------|
| 1 | Power LED YELLOW | Only one power supply is working | Connect another power supply |
| 2 | Status LED GREEN Laser LED GREEN RF LED RED POWER LED YELLOW | No RF Input | Connect RF signal at the Input |
| 3 | Status LED RED Laser LED RED RF LED RED LCD Display "KEY OFF" | The key is turned to OFF | Turn the key to ON |
| 4 | Output power LCD displays normal value, but optical power meter displays low value | Output interface of patch cord is dirty or | Clean the output interface |
| | | Power meter error | Change power meter |

7 EU Declaration of Conformity

The product Declaration of Conformity can be downloaded from the product page at www.com.com

8 Conditions of warranty

TRIAX UK warrants the product as being free from defects in material and workmanship for a period of 24 months starting from the date of production indicated on it. See note below.

If during this period of warranty, the product proves defective, under normal use, due to defective materials or workmanship, TRIAX UK, at its sole option, will repair or replace the product. Return the product to your local dealer for reparation.

THE WARRANTY IS APPLIED ONLY FOR DEFECTS IN MATERIAL AND WORKMANSHIP AND DOES NOT COVER DAMAGE RESULTING FROM:

- Misuse or use of the product outside of its specifications,
- Installation or use in a manner inconsistent with the technical or safety standards in force in the country where the product is used,
- Use of non-suitable accessories (power supply, adapters...),
- Installation in a defective system,
- External cause beyond the control of TRIAX UK such as drop, accidents, lightning, fire, ...

THE WARRANTY IS NOT APPLIED IF

- Production date or serial number on the product is illegible, altered, deleted or removed.
- The product has been opened or repaired by a non-authorized person.

NOTE

Date of production can be found in the product's serial number code. The format is "YYWW123456 (YEAR, WEEK, 123456 product unique number), e.g. 2532000020 = year 2025 week 32, product No.20 of this batch.

