

International Offices

U.S.A
17595 Mt. Herrmann Street
Fountain Valley, CA. 92708
TEL: 714-885-6000
Fax: 866-743-4905
URL: www.dlink.com

Canada
2180 Winston Park Drive
Oakville, Ontario, L6H 5W1
Canada
TEL: 1-905-8295033
FAX: 1-905-8295223
URL: www.dlink.ca

Europe (U. K.)
4th Floor, Merit House
Edgware Road, Colindale
London NW9 5AB
U.K.
TEL: 44-20-8731-5555
FAX: 44-20-8731-5511
URL: www.dlink.co.uk

Germany
Schwalbacher Strasse 74
D-65760 Eschborn
Germany
TEL: 49-6196-77990
FAX: 49-6196-7799300
URL: www.dlink.de

France
Le Florilege #.2, Allee de la
Fresnerie
78330 Fontenay le Fleury
France
TEL: 33-1-30238688
FAX: 33-1-30238689
URL: www.dlink-france.fr

Netherlands
Weena 290
3012 NJ Rotterdam
Netherlands
Tel: +31-10-282-1445
Fax: +31-10-282-1331
URL: www.dlink-benelux.com

Norway
Karihaugveien 89
1086 Oslo
Norway
TEL: 47-22-309075
FAX: 47-22-309085
URL: www.dlink.no

Finland
Pakkalankuja 7A
01510 Vantaa,
Finland
TEL: +358-9-2707 5080
FAX: +358-9-2707 5081
URL: www.dlink.fi

Iberia
C/Sabino De Arana,
56 Bajos
08028 Barcelona
TEL: 34 93 4090770
FAX: 34 93 4910795
URL: www.dlinkiberia.es

Singapore
1 International Business Park
#03-12 The Synergy
Singapore 609917
TEL: 65-6774-6233
FAX: 65-6774-6322
URL: www.dlink-intl.com

Australia
1 Giffnock Avenue,
North Ryde, NSW 2113
Australia
TEL: 61-2-8899-1800
FAX: 61-2-8899-1868
URL: www.dlink.com.au

India
D-Link House, Kurla Bandra
Complex Road,
Off CST Road, Santacruz
(East),
Mumbai - 400098, India
TEL:
91-022-26526696/56902210
FAX: 91-022-26528914
URL: www.dlink.co.in

Israel
11 Hamanofim Street
Ackerstein Towers, Regus
Business Center
P.O.B 2148,
Hertzelia-Pituach 46120.
Israel
TEL: +972-9-9715700
FAX: +972-9-9715601
URL: www.dlink.co.il
LatinAmerica
Isidora Goyechea 2934 of
702,
Las Condes
Santiago - Chile S.A.
TEL: 56-2-232-3185
FAX: 56-2-232-0923
URL: www.dlink.cl

Brasil
Av das Nacoes Unidas,
11857 - 14th andar - cj
141/142
Brooklin Novo
Sao Paulo - SP - Brazil
CEP 04578-000 (Zip Code)
TEL: +55 11 55039320
FAX: +55 11 55039322
URL:
www.dlinkbrasil.com.br

South Africa
Einstein Park II
Block B
102-106 Witch-Hazel
Avenue
Highveld Technopark
Centurion/Gauteng
Republic of South Africa
TEL: 27-12-665-2165
FAX: 27-12-665-2186
URL: www.d-link.co.za

Russia
Grafsky per., 14, floor 6
Moscow
129626 Russia
TEL: 7-095-744-0099
FAX: 7-095-744-0099 #350
URL: www.dlink.ru

China
No.202,C1 Building,
Huitong Office Park,
No.71, Jianguo Road,
Chaoyang District,
Beijing,100025, China.
TEL: +86-10-58635800
FAX: +86-10-58635799
URL: www.dlink.com.cn

Belgium
Rue des Colonies 11
B-1000 Brussels
Belgium
Tel: +32(0)2 517 7111
Fax: +32(0)2 517 6500
URL: www.dlink-benelux.com

Italy
Via Nino Bonnet n. 6/b
20154 - Milano,
Italy
TEL: 39-02-2900-0676
FAX: 39-02-2900-1723
URL: www.dlink.it

Sweden
P.O. Box 15036, S-167 15
Bromma
Sweden
TEL: 46-(0)8564-61900
FAX: 46-(0)8564-61901
URL: www.dlink.se

Denmark
Naverland 2, DK-2600
Glostrup, Copenhagen,
Denmark
TEL: 45-43-969040
FAX: 45-43-424347
URL: www.dlink.dk

Middle East (Dubai)
P.O.Box: 500376
Office No.:103, Building:3
Dubai Internet City
Dubai, United Arab Emirates
Tel:+971-4-3916480
Fax:+971-4-3908881
URL: www.dlink-me.com

Turkey
Regus Offices
Beybi Giz Plaza,
Ayazaga Mah. Meydan Sok.
No:28
Maslak 34396, Istanbul-Turkiye
TEL: +90 212 335 2553
FAX: +90 212 335 2500
URL: www.dlink.com.tr

Egypt
19 El-Shahed Helmy, El Masri
Al-Maza, Heliopolis
Cairo, Egypt.
TEL: +202 414 4295
FAX: +202 415 6704
URL: www.dlink-me.com

Taiwan
2F, No. 119, Pao-Chung Rd.
Hsin-Tien, Taipei
Taiwan
TEL: 886-2-2910-2626
FAX: 886-2-2910-1515
URL: www.dlinktw.com.tw

Headquarters
2F, No. 233-2, Pao-Chiao
Rd.
Hsin-Tien, Taipei
Taiwan
TEL: 886-2-2916-1600
FAX: 886-2-2914-6299
URL: www.dlink.com.tw

D-Link®

Building Networks for People



1000Base-T to 1000Base-SX/LX
Media Converter
Manual

TABLE OF CONTENTS

TABLE OF CONTENTS	2
INTRODUCTION	3
ABOUT MEDIA CONVERTER	3
PRODUCT FEATURES	4
INSTALLATION.....	5
SELECTING A SITE FOR THE EQUIPMENT.....	5
CONNECTING TO POWER	5
INSTALLING IN A CHASSIS	5
MONITORING THE CONVERTER THROUGH MANAGEMENT MODULE	6
LED INDICATOR	7
LINK PASS THROUGH FUNCTION	7
SWITCH.....	9
SPECIFICATIONS	10

INTRODUCTION

Thank you for choosing the 1000Base Gigabit Ethernet Media Converter, The Converter introduced here provides one channel media conversion between 1000BASE-TX and 1000BASE-FX.

About Media Converter

Media Converter is a network technology specified by IEEE 802.3ab and IEEE 802.3z 1000BASE-TX/FX standards.

PRODUCT FEATURES

- Hot-swappable when used with a chassis
- One-channel media conversion between 1000BASE-TX and 1000BASE-FX
- Fiber media allows: multi-mode fiber and single-mode fiber using SC connector
- Link Pass Through function
- Auto negotiation of duplex mode on TX port
- Auto MDI/MDI-X for TX port
- Full wire-speed forwarding rate
- Front panel status LEDs
- Used as a stand-alone device or with a chassis
- Hot-swappable when used with a chassis

INSTALLATION

This chapter gives step-by-step installation instructions for the Converter.

Selecting a Site for the Equipment

As with any electric device, you should place the equipment where it will not be subjected to extreme temperatures, humidity, or electromagnetic interference. Specifically, the site you select should meet the following requirements:


1. The ambient temperature should be between 32 and 104 degrees Fahrenheit (0 to 40 degrees Celsius).
2. The relative humidity should be less than 90 percent, non-condensing.
3. Surrounding electrical devices should not exceed the electromagnetic field (RFC) standards for IEC 801-3, Level 2 (3V/M) field strength.
4. Make sure that the equipment receives adequate ventilation. Do not block the ventilation holes on each side of the switch or the fan exhaust port on the side or rear of the equipment.
5. The power outlet should be within 1.8 meters of the switch.

Connecting to Power

1. This Converter is a plug-and-play device.
2. Connect the supplied AC to DC power adaptor with a power voltage of 7.5Vdc/1.5Amp to the DC-Jack on the converter, and then attach the plug into a standard AC outlet.


Installing in a Chassis

The Converter can be fit into any of the expansion slots on a special designed chassis.



• First, install the converter onto a carrier supplied with the chassis:


- Step 1- Unscrew and pull out the media converter board.
- Step 2- Plug in the media board to any of the vacant slot.
- Step 3- Fit the converter onto the carrier and use the screw to secure it.



Monitoring the Converter through Management Module

There is a **management module** that can control this media converter through the **chassis system**, this media converter can be controlled through Web Browser, SNMP and terminal emulation program.

The **management module** will detect the default reset on the DIP switches and display out the status, also the **management module** can control the function through the **chassis system**.



NOTE: To control the function in a working station, need to collocate together with optional Chassis System and Management Module.

LED Indicator

The LED indicators give you instant feedback on status of the converter:

PWR ○ LINK/ACT

LEDs	State	Indication
Power (PWR)	Lights on	Power on
	Lights off	Power off
Link and Activity (LINK/ACT)	Lights on	Linking
	Lights Blinking	Data transmitting and receiving
	Lights off	Not Linking

Link Pass Through Function

LLCF (Link Loss Carry Forward)

When a device connected to the converter and the TP line loss the link, the converter's fiber will disconnect the link of transmit, so that the other ends will know that there is a linkage error on this end. And when the Fiber line loss the link, the converter's TP will disconnected, and the other end will know that there is linkage problem exist.

There is a default LLCF setting on this converter.

Registration Card

Print, type or use block letters.

Your name: Mr./Ms _____ Dept. _____
 Organization: _____
 Your title at organization: _____
 Telephone: _____ Fax: _____
 Organization's full address: _____ Country: _____

Date of purchase (Month/Day/Year): _____


Product Model	Product Serial No.	* Product installed in type of computer (e.g., Compaq 486)	* Product installed in computer serial No.

(* Applies to adapters only)
 Product was purchased from: _____
 Reseller's name: _____
 Telephone: _____ Fax: _____
 Reseller's full address: _____

Answers to the following questions help us to support your product:

1. *Where and how will the product primarily be used?*
 Home Office Travel Company Business Home Business Personal Use
2. *How many employees work at installation site?*
 1 employee 2-9 10-49 50-99 100-499 500-999 1000 or more
3. *What network protocol(s) does your organization use ?*
 XNS/PX TCP/IP DECnet Others _____
4. *What network operating system(s) does your organization use ?*
 D-Link LANsmart Novell NetWare NetWare Lite SCO Unix/Xenix PC NFS
 3Com 3+Open Banyan Vines DECnet Pathwork Windows NT
 Windows NTAS Windows '95 Others _____
5. *What network management program does your organization use ?*
 D-View HP OpenView/Windows HP OpenView/Unix SunNet Manager
 NovellMS NetView6000 Others _____
6. *What network medium/media does your organization use ?*
 Fiber-optics Thick coax Ethernet Thin coax Ethernet 10BASE-T UTP/STP
 100BASE-TX 100BASE-T4 100VGAnyLAN Others _____
7. *What applications are used on your network?*
 Desktop publishing Spreadsheet Word processing CAD/CAM
 Database management Accounting Others _____
8. *What category best describes your company?*
 Aerospace Engineering Education Finance Hospital Legal
 Insurance/Real Estate Manufacturing Retail/Chainstore/Wholesale
 Government Transportation/Utilities/Communication VAR
 System house/company Other _____
9. *Would you recommend your D-Link product to a friend?*
 Yes No Don't know yet
10. *Your comments on this product?* _____

The table below shows how LLCF function is working:



Link Status	Link 1	Link 2	Link 3	Link 4
Disconnect				
Cable 1	Off	On	On	On
Cable 2	Off	Off	Off	Off
Cable 3	On	On	On	Off
Cable 4	Off	Off	Off	Off
Cable 5	Off	Off	Off	Off


LLR (Link Loss Return)

When a device connected to the converter and the fiber line loss the link, the converter's fiber will disconnect the link of transmit.

There is a switch to enable or disable the function of the media converter.


The table below shows how LLR function is working:

Media Converter	LLR	Auto-Negotiation
A	ON	OFF
B	OFF	OFF



Link Status	Link 1	Link 2	Link 3	Link 4
Disconnect				
Cable 1	Off	Off	Off	Off
Cable 2	Off	On	On	Off
Cable 3	Off	Off	Off	Off
Cable 4	Off	Off	Off	Off

NOTE: If connecting two converters with LLR function in both end, it is recommended that the monitor end converter had to turn off the LLR function, and turn on the LLR function of the remote end converter.



Switch

There is a two pin DIP switch on the module which define as switch 1 and switch 2:

Switch 1: Fiber mode switch

When the switch was turned to "On", it means that the fiber was turned to forced mode, and "Off" for auto-negotiation mode.

Note: Be sure the opposite end is using the same setting (forced or Auto-negotiation). And when using two converters at the same time, the two converters MUST set to forced mode.

Switch 2: LLR

When the switch was turned to "On", it means that the LLR was enabled and "Off" for disabled.

Note: When using two converters, don't enable the both device's LLR function at the same time.